SHORE MATE®

FIRST BY DESIGN

INSTRUCTIONS TO FLUSH HYDRAULIC PUMP

1. Drain or pump fluid from pump reservoir.
2. Loosen the hose clamp which holds the tank on the pump.
3. Remove the tank.
4. Remove the screen pick-up tube using channel locks or pliers.
5. Wash both the tank and pick-up tube with a strong detergent. This may require several minutes under hot water. Generally, the pick-up tube is plugged extensively.
6. Re-install pick-up tube.
7. Re-install tank and tighten hose clamp.
8. Replace hydraulic fluid.