

# SHORE MATE®

**FIRST BY DESIGN**

## ***BOAT LIFTS & DOCKS***

### **General Care Instructions for your Hydraulic Boat Lift**

We strongly recommend that you install a Deep Cycle Marine battery, 12V, Group 27 or 29. There are two types of Marine batteries, *Trolling* and Starting. Purchase a trolling rated battery. Batteries with high ratings for “Cold Cranking”, i.e. Starting, will have a much shorter lifespan. *Recommended battery: **Marine Deep Cycle Battery – 27 Series***

If equipped, your radio remote control feature requires a minimum of 9 volts to operate. A weak battery may cause intermittent operation. Charge or replace the battery.

Take care to keep the inside of the pump box clean. This may assist in extending the life of your battery. If you notice continued dripping or pooling of fluid there is a larger issue to check out.

Keep the quick disconnect fittings free from contaminants. These can contaminate the fluid and cause the lift to fail prematurely.

The fluid in your lift was chosen to have a minimal environmental impact in the event of a leak yet provide dependable, long-term service. If necessary, please contact your dealer or Shore-Mate to purchase replacement fluid. We recommend replacing the fluid every three to five years.